


地 番	25—6~25—9・17
	25—13~25—10



1

25-6				
1	20	15	9	918
2	20	15	9	77
計				396
1/2				198
25-7				
1	20	49	9	99
2	20	49	10	182
計				413
1/2				206
25-8				
1	20	27	10	04
2	20	27	9	86
計				403
1/2				201
25-9				
1	18	59	8	92
2	18	59	7	62
3	12	64	2	51
4	9	83	2	07
5	11	43	2	57
計				388
1/2				194
25-17				
1	3	46	1	62
2	5	70	0	98
3	5	70	1	984
計				22
1/2				11

25-10				
NO	底	辺	高	サ
1	11	44	2	50
2	18	41	5	85
3	10	39	2	08
4	18	61	3	99
5	18	61	8	581
計				391
1/2				195
25-11				
1	20	45	10	096
2	20	45	10	09
				412
1/2				206
25-12				
1	20	51	10	136
2	20	51	9	94
計				411
1/2				205
25-13				
1	20	49	9	92
2	20	49	10	086
計				409
1/2				204